

COATING SPECIFICATION

SUBSTRATE: Exterior Woodwork - Repaint

SURFACE PREPARATION & APPLICATION:

- Proper surface preparation is crucial to maximum finish performance. The durability of this product can be impaired by an unsound or poorly prepared surface.
- Scrape any loose and flaking paint. Sand flush any edges and remove dust.
- The bottom panels and lower end of side panels are especially likely to be in poor condition, pay particular attention to these areas.
- Apply products evenly with a good quality synthetic bristle brush. Do NOT use a natural bristle brush with water based products.

COATING:

- Spot prime bare areas with 2 coats of Prime1 ACRYLIC.
1st coat: Colourtrend Prime1 ACRYLIC.
- Fill with suitable filler and sand where required. Remove dust.
3rd coat: Colourtrend Gloss or Satin in desired colour
4th coat: Colourtrend Gloss or Satin in desired colour*

*Some colours may require extra coats

NOTES:

- Coating will achieve full adhesion after seven days
- For greater block resistance we recommend using Colourtrend Gloss

* Some colours may require extra coats.



INFINITE COLOUR *from* IRELAND

Colourtrend, Maynooth Road, Celbridge, Co Kildare, W23 X7R8, Ireland
t: +353 1 6288224 f: +353 1 6272205 e: info@colourtrend.ie

IMPORTANT NOTE: The information contained in this specification sheet is not intended to be conclusive. It is for guidance and is given in good faith. Whilst we attempt to ensure that all advice we give about our products, whether in this sheet or otherwise, is correct, we have no control over the quality or condition of the substrate or the many factors affecting the use and application of this product. Many such factors are beyond our control and it is always good practice to conduct a trial area in advance to ensure a satisfactory result.