

COATING SPECIFICATION

SUBSTRATE: Interior Blockwork – New – Paint

SURFACE PREPARATION:

- Ensure surface is clean, dry and sound.
- Allow blockwork to dry out. When dry the surface will be an even colour. This may take up to a week depending on temperature and humidity.
- Fill all gaps which are subject to movement, e.g. plaster to door-frame, plaster to skirting, with elastomeric acrylic caulk (we recommend the Allpro range).

COATING:

1st coat: Colourtrend Interior Matt diluted with up to 5% water in desired colour.

2nd coat: Colourtrend Interior Matt in desired colour.

3rd coat: Colourtrend Interior Matt in desired colour*.

APPLICATION:

- Brush, roll or spray.
- Spray followed by back rolling is recommended as the optimum application method for concrete block or other porous masonry surfaces.
- Ensure good drying conditions and ventilation during application and drying.
- Do not apply if surface or ambient temperature is below 10°C.

NOTES:

For a soft-sheen finish the third coat should be replaced with Colourtrend Soft Sheen.

*Some colours may require extra coats



INFINITE COLOUR *from* IRELAND

Colourtrend, Maynooth Road, Celbridge, Co Kildare, W23 X7R8, Ireland
t: +353 1 6288224 f: +353 1 6272205 e: info@colourtrend.ie

IMPORTANT NOTE: The information contained in this specification sheet is not intended to be conclusive. It is for guidance and is given in good faith. Whilst we attempt to ensure that all advice we give about our products, whether in this sheet or otherwise, is correct, we have no control over the quality or condition of the substrate or the many factors affecting the use and application of this product. Many such factors are beyond our control and it is always good practice to conduct a trial area in advance to ensure a satisfactory result.