

COATING SPECIFICATION

SUBSTRATE: Interior Plaster - New

COATING:

1st coat: Colourtrend Prime4 PSU in desired colour diluted with 5-10% water.

2nd coat: Colourtrend Prime4 PSU in desired colour

3rd coat: Colourtrend Interior Matt in desired colour

4th coat: Colourtrend Interior Matt in desired colour*

SURFACE PREPARATION:

- Allow plaster to dry out. When dry the plaster will be an even colour. This may take up to a week after plastering depending on temperature and humidity.
- Ensure plaster is sound. Clear tape applied to the dry plaster should remove cleanly without any plaster / powder removal.
- Fill any holes with appropriate filler. Fill all gaps which are subject to movement, e.g. plaster to door-frame, plaster to skirting, with elastomeric acrylic caulk (we recommend the Allpro range).
- Sand lightly to ensure flush finish. Remove dust.

APPLICATION:

- Brush, roll or spray
- Ensure good drying conditions and ventilation during application and drying.
- Do not apply if surface or ambient temperature is below 10°C.

NOTES:

- For a soft sheen finish the fourth coat should be replaced with Colourtrend Soft Sheen.
- Powdery or problematic interior plaster surfaces, which require a high binding primer, should be treated with Colourtrend Weather Stabilising Primer. A test area should be treated in advance to ensure satisfactory results.

*Some colours may require extra coats



INFINITE COLOUR *from* IRELAND

Colourtrend, Maynooth Road, Celbridge, Co Kildare, W23 X7R8, Ireland
t: +353 1 6288224 f: +353 1 6272205 e: info@colourtrend.ie

IMPORTANT NOTE: The information contained in this specification sheet is not intended to be conclusive. It is for guidance and is given in good faith. Whilst we attempt to ensure that all advice we give about our products, whether in this sheet or otherwise, is correct, we have no control over the quality or condition of the substrate or the many factors affecting the use and application of this product. Many such factors are beyond our control and it is always good practice to conduct a trial area in advance to ensure a satisfactory result.